

TRUCK "SUPRA RANGE"

Units	Oil Filter on Diesel Engine	Oil filter	If by-pass oil filter	Fuel filter	Filter drier	Air Filter Drier	Air Filter Element	Air Filter Oil Bath
Supra 950 / 950 MT (R404A)	-	30-00323-00	-	30-00302-00	14-00326-03	30-60075-00	30-60049-20	-
Supra 950 / 950 MT (R404A) Silent Version	-	30-00323-00	-	30-00302-00	14-00326-03	30-60097-00	30-60097-20	-
Supra 922	-	30-00323-00	30-00302-00	30-00302-00	14-00326-00	30-60073-00SK → or 30-60021-00 →	30-60049-20 941070	-
Supra 922 starting S/N : TA901968	-	30-00323-00	30-00302-00	30-00302-00	14-00326-00	30-60075-00	30-60049-20	-
Supra 944	-	30-00323-00	30-00302-00	30-00302-00	14-00326-03	30-60073-00SK → or 30-60021-00 →	30-60049-20 941070	-
Supra 944 starting S/N : TA902364	-	30-00323-00	30-00302-00	30-00302-00	14-00326-03	30-60075-00	30-60049-20	-
Supra 850 / 850 MT (R404A)	941172	-	30-00302-00	30-00302-00	14-00326-03	30-60075-00	30-60049-20	-
Supra 822	941172	30-00302-00	30-00302-00	30-00302-00	14-00326-07 (Flare) prior S/N : T501259 14-00326-00 (ORFS) starting S/N : T501259	30-60021-00	941070	30-01030-01
Supra 822 model 98 Starting S/N : T801424	941172	30-00302-00	30-00302-00	30-00302-00	14-00326-00	30-60075-00	30-60049-20	-
Supra 844	941172	30-00302-00	30-00302-00	30-00302-00	14-00326-03	30-60021-00	941070	30-01030-01
Supra 844 model 98 starting S/N : T801564	941172	30-00302-00	30-00302-00	30-00302-00	14-00326-03	30-60075-00	30-60049-20	-
Supra 750 / 750 MT	941172	-	30-00302-00	30-00302-00	14-00326-03	30-60075-00	30-60049-20	-
Supra 722	941172	30-00302-00	30-00302-00	30-00302-00	14-00326-07 (Flare) prior S/N : T501087 14-00326-00 (ORFS) starting S/N : T501087	30-60021-00	941070	30-01030-01
Supra 722 model 98 starting S/N : T800479	941172	30-00302-00	30-00302-00	30-00302-00	14-00326-00	30-60075-00	30-60049-20	-
Supra 744	941172	30-00302-00	30-00302-00	30-00302-00	14-00326-03	30-60021-00	941070	30-01030-01
Supra 744 model 98 starting S/N : T800487	941172	30-00302-00	30-00302-00	30-00302-00	14-00326-03	30-60075-00	30-60049-20	-
Supra 550	941172	-	30-00302-00	30-00302-00	14-00326-03	30-60075-00	30-60049-20	-
Supra 522	941172	30-00302-00	30-00302-00	30-00302-00	14-00326-07 (Flare) prior S/N : T500928 14-00326-00 (ORFS) starting S/N : T500928	30-60021-00	941070	30-01030-01
Supra 522 model 98 starting S/N : T800934	941172	30-00302-00	30-00302-00	30-00302-00	14-00326-00	30-60075-00	30-60049-20	-
Supra 544	941172	30-00302-00	30-00302-00	30-00302-00	14-00326-03	30-60021-00	941070	30-01030-01
Supra 544 model 98 starting S/N T801133	941172	30-00302-00	30-00302-00	30-00302-00	14-00326-03	30-60075-00	30-60049-20	-
Supra 450	941172	-	30-00302-00	30-00302-00	14-00326-03	30-60075-00	30-60049-20	-
Supra 422	941172	30-00302-00	30-00302-00	30-00302-00	14-00326-00	30-60021-00	941070	-
Supra 422 / Supra 322 model 98	941172	30-00302-00	30-00302-00	30-00302-00	14-00326-00	30-60075-00	30-60049-20	-
Supra 444 model 98	941172	30-00302-00	30-00302-00	30-00302-00	14-00326-03	30-60075-00	30-60049-20	-
Supra 422 AL	941172	30-00302-00	30-00302-00	30-00302-00	14-00326-00	30-60021-00	941070	-